

Digital Motor Protection Relay

<DSP-CCL,485 Communication>



Sam
Wha DSP Ltd.



Contents

1. Abstraction
2. Main Feature
3. Function
4. Technical Specification
5. Preset Description
6. The order of Rotated Mode
7. Input-Output terminal
8. Operation of Control key
9. Trip Indication
10. Rotated Indication
11. Time Based Trip Relay Output
12. T-I Characteristic
13. Application Sequence Diagram
14. Dimension
15. Order Form

Digital Motor Protection Relay

<DSP-CCL,485 Communication>

1.Abstraction

Installation	Model	Protection	Description
Panel Mounting Type	DSP-CCL	Over/Under Current,Phase Loss,Reverse Phase,Locked Rotor,Current unbalance, Ground Fault, Shock/Stall	Password,self-diagnostics, Alarm ,RS485 communication
Panel Mounting Type			
			

2. Main Feature

- To give a guarantee to authorized operator: Password
- MCU based digital control : precised motor protection
- Compact size, Multi-function
 - *Protection : Over current/Under current/Phase loss/Reverse phase /Locked rotor/Shock(Stall)/Current unbalance,Ground fault
 - *Indication :Current/L1, L2, L3 , earth current, load factor ,accumulated working time[AWT]
 - *Digital communication : RS485
- To cover a wide and precised current range for the protection
 - *10 Type : 0.5A ~ 10A or exclusively for external CT/ 0.5A~6A
 - *70 Type : 5A ~ 70A
 - *Extended current range with external CT : 1A ~ 1200A
- To show a trip cause and operation information in character and/or number : 5 Digit Window
- "Shock" protection : useful for instant mechanical shock due to over load while crasher,roller,conveyer,etc are working

- To indicate a necessary information in every 3 sec
- Convenient installation of ZCT to sense a zero phase current for GF protection
 - *Standard type : to use external ZCT(200mA/1.5mA)
 - *Optional type : to use embedded ZCT(not available for external CT application)
- High sensitive level and wide range for ground fault protection :
30mA ~ 2A/Zero-phase sequence current
- To response for digital network communication through 485,Modbus /RTU
 - :possible to monitor by "samdsp"
 - :possible to store 2 cycle wave of trip instant/to check correct trip cause
- Various way for reset: Manual or Automatic /to response flexibly for applied sequence system
- To keep a stable operation under frequency variation from Inverter :
30Hz ~ 400Hz
- Self-diagnostic test by one touch for "SET" key
- Alarm before Tripping by over current
- To memorize latest number of 8 among trip events

3. Function

Protection	Operating time	Description
Over current	·d-time :1 ~ 300sec/def. ·o-time :Definite/1 ~ 60sec :Inverse/5~30 Class	·to protect over current of each phase /L1,L2,L3
Under current	·U-time :1 ~ 30 sec/def.	·to protect under current of each phase /L1,L2,L3
Current unbalance	8 sec	·adjustable:30% ~ 90%: ·rate=[(max-min)/max]*100[%]
Phase loss	1~5 sec	·to protect phase loss of each phase , L1,L2,L3, based on load current
Reverse phase	within 0.5 sec	·to protect reverse phase based on load current
Locked rotor	dt + 0.1 sec	·to protect locked rotor in starting state
Shock/ Stall	0.5 ~ 3sec/def.	·to make a trip if preset value is sensed during working ·preset range to "OC" :180% ~ 700%
Ground fault	Edt:1 ~ 25sec, Eot:0.1 ~ 30sec/def	· to protect GF by zero phase sequence current sensed through ZCT

Indication	Description
Rotated indication during the operation	*Indication in every 3 sec :3 phase current >> Earth current >>AWT >> Load factor *Load factor :[actual running current / preset value of "oc"] *AWT:accumulated working time *Possible to fix one of rotated factor or to release :repeated one touch with "CLR" key
To check preset value of each mode during the operation	* Possible to check a value and a mode as pressing "SET" key once during the operation * preset value and mode are appeared alternatively * possible to check next mode as pressing "CLR" Key * Return to operating mode as pressing both "SET" and "CLR" key in the same time or waiting for 10sec
Alarm	* Able to make alarm before tripping if actual current is kept over preset alarm rate to "OC" preset value over 3 sec * Preset value is flickeing
Aux	Description
RS485	*Available only for CCL Type *Possible to monitor the operation data by "Samdsp", "samsdpdb"

4. Technical Specification

DIV		Description
Load Current range	10 Type	0.5A ~ 10A or external CT(0.5~6A)
	70 Type	5A ~ 70A
	With External CT	1A ~ 1200A
Ground fault Current	Zero phase current	*30mA ~ 2A *sensed through external ZCT or embeded ZCT
Time preset	Starting delay time(dt)	1 ~ 300 sec/def.
	over current trip delay time(ot)	*1 ~ 60 sec/def. *5 ~ 30Class/inverse
	under current trip delay time(ut)	1 ~ 30sec/def.
	Ground fault starting delay time(Edt)	OFF, 1 ~ 25 sec/def.
	Ground fault trip delay time(Eot)	*0.1 ~ 30 sec/def.
	Shock/stall trip delay time(st)	0.5 ~ 3sec/def
	Phase loss trip delay time(PLc)	1~5sec/def
Allowable tollerance	Current	$C \leq 2A: 0.2A, C > 2A: \pm 5\%$
	Time	$t \leq 2sec: \pm 0.2ec, t > 2sec: \pm 10\%$
Control power		*AC 85V ~ AC260V, 50/60Hz (DC90V ~ DC370V)
		*DC24V(Optional)

Trip output relay		Main:95-96-98		1c(1-SPDT),3A/Resistive
		Aux:05-06-08		1c(1-SPDT),3A/Resistive(possible to alarm output one of Ec/Ect/AL/uc/Shoc
Application environment		temperature	Operation	-25 ^o C ~ +70 ^o C
			Storage	-40 ^o C ~ +80 ^o C
		Humidity		30 ~ 85%/Relative,non-condensing
Current tollerance against changeable frequency from inverter				Average +,- 5%,30Hz ~ 400Hz
Max Main Conductor Size				25SQ
Screw Torque				Max 0.6 N.m
Insulation Resistance/IEC-60255-5				100Mohm or more/500VDC,circuit-case
High Voltage Withstand Test/ IEC-60255-5				*circuit-case:AC2000V,60Hz, 1 min *contact-contact:AC1000V,60Hz,1min
Lightning Impulse Voltage Withstand Test)/ IEC-60255-5				*Circuit-Ground,Circuit-Circuit:1.2/50uS, 5KV *Control Circuits:1.2/50uS, 5KV
1 MHz Burst Immunity Test:IEC 61000-4-18				2.5KV,Positive/Negative under 2sec
Electrostatic Discharge: IEC-61000-4-2				Air:Level 3, 8KV,Contact:Level 3,6KV
Radiated Electromagnetic Field Disturbance:IEC-61000-4-3				Level 3, 10V/m
Electric Fast Transient Burst :IEC-61000-4-4				Power,Realy output:Level 4, 4KV
Surge Immunity test:IEC-61000-4-5				Relay output:1.2X50uS,2KV (0°,90°,180°,270°)
Conducted Disturbance Test: IEC-61000-4-6				10V,Level 3
Digital communication	CCL	RS 485	Physical	2 wire RS 485,Modbus/RTU
			Address	1 ~ 250
			Speed	9.6/19.2/38.4/57.6/76.8/115.2kbps
			Connection	Terminal:TRX(,),TRX(-)
			Termination resistance	it needs to use external resistance with 120 Ω
			Cable	Sheathed 2 Pair
Power consumption				6W Max

5.Preset Description

► Main Mode

Press "SET" key to enter into setting mode ,then enter password. The more detail is described in "Operation of Control key "

Mode	Function/ range	Description	Factory Setting value
P*****	Password	*need to input a number of digit , "0000" to enter setting mode *need to move a cursor from first digit(1000unit) to last unit(1unit) to pass over next mode as pushing CLR key(Enter function) 4 times. *possible to change password in "PEdIt" mode in CAB mode group	0000
Out/a/b	to define the pattern of main trip output in initial state	*Trip output : 1c(95-96-98) *a:output state is changed from the original state as the control power is ON/96-96→open,95-98→close *b:output state is not changed from the original state as the control power is ON/96-96→close, 95-98→open	b
CtO/1t/ 5A	to sense a current/ DSP in itself or combined with external CT	*1t:current is sensed through its own CT, next "ct" mode is not appeared automatically *5A:a secondary current rating of external CT is 5A/extended current range is calculated based on 0.2A ~ 6A	1t
ct/setting value	to preset a ratio of external CT	*This mode is available for 10 Type *To preset CT ratio[primary value /5] *CT ratio : 1~240 *1:to sense a current through its own CT or external CT with 5/5 ratio	"ct--"
oc/ setting value	to preset a range to protect over current	*current range for over current protection *10 Type : 0.5A ~ 10A or for external CT/0.5A ~ 6A *70 Type: 5A ~ 70A	*10:10A *70:70A
dt/OFF/ setting value	to preset starting delay time	*Trip delay time to prevent unwanted trip caused by starting current *1 ~ 300sec *available for sensing current over 0.2A , otherwise preset dt is not adopted internally	5sec

Otc/deF/ Inv	to select time-current characteristics for over current protection	*to decide T-I characteristics: deF/Inv *deF(definite):trip based on preset value for "OC" and "ot" *inverse ▶dt=0 : trip based on cold curve ▶dt>0 :trip based on hot curve after dt is elapsed(actually dt+calculated time in inverse curve) ▶Available multiple value in each type: -10Type:1~(30/"OC" prset value) -70Type:1~(210/"OC" prset value)	deF
Ot/ setting value	to preset trip delay time	*to preset time to make a trip when a current exceeds preset value *definite:1sec ~ 60sec *inverse:5 ~ 30 Class	5sec
Lc/oFF /on	to protect Locked Rotor	*OFF:disable for this mode *ON:to make a trip in 0.1sec after eleapsed dt("Otc"=def,inv) if starting current exceeds 300% to oc preset value during dt	OFF
Shoc/ oFF/setting value	Shock protection during working	*OFF:disable for this function *preset to "OC":followed calculation /max 700% -10Type:180% ~ [30/"OC"preset value] % -70Type:180% ~ [210/"OC" preset value] %	oFF
st/setting value	to preset a time for shock protection	*0.5 ~ 3sec/def. *this mode is shown as "st--" if shock mode is disable	"st--"
PLc /oFF/ on	to protect phase loss by load current	*OFF:disable *ON:to make a trip to protect phase loss based on load current *preset time:1~5 sec	OFF
RPc /oFF/ on	to protect reverse phase by load current	*OFF:disable *ON:to make a trip to protect reverse phase based on load current within 0.5sec	OFF
Ec/oFF/ setting value	to preset zero phase current	*for ground fault protection *OFF:disable *sensitive range:30mA ~ 2A	OFF
Edt/oFF/ setting value	to preset starting trip delay time	*definite T-I *preset range :1 ~ 25sec *this mode is shown alternatively as "Edt" & "--" if Ec mode is disable	"--"
Eot /setting value	to preset operating	*0.1 ~ 30sec/def. *this mode is shown alternatively as	"--"

	trip delay time for GF protection	"Eot" & "--" if Ec mode is disable	
uc/oFF/ setting value	to preset a range to protect under current	*preset range:0.6A ~ under "OC" preset value *In case preset "OC" value is under 0.7A, "UC" function is not available	OFF
ut/setting value	to preset trip delay time for under current	*1 ~ 30sec	--
ub/oFF/ value	to define current unbalance rate	*to protect current unbalance among each phase *calculation : [(max-min)/max]*100[%] *preset range : 30% ~ 90%	50%
Au-o/oFF/Ec/AL/uc/ Shoc/Ec-tb	to preset a kind of AUX (07-08-10) trip output	*oFF:to make same output as main trip *trip output for AL/Uc/Shoc/Ec is independent from main trip and selected factor is not available in main trip,also if trip cause is clear, this trip output is reset naturally *Ec:only for ground fault protection *Uc:only for under current protection *shoc:only for shock protection *AL:only for alarm to oc before trip *Ec-tb:only for ground fault protection ,but this is not reset even if trip cause is clear,also main trip is acted with this aux trip together -Ec-tb:initial state of AUX output is open(de-energized)	OFF
AL/ setting value	to preset alarm level rate(%) to "OC"	*if other factor except "AL" in "Auo" mode is preset, this mode is shown "AL--" *preset range to "OC" :65% ~ 100% *alarm is come out as the condition of preset alarm % is keeping for 3 sec or more	90

ALt/ setting value & Clear	to preset a limit of accumulated working time necessary to give alarm & clear	*possible to preset a value between 0.1 hr ~ 6553.5 hr by 0.1 hr unit *able to accumulate time in case 0.2A or more is sensed *indicated value is flickering as preset value is elapsed *To clear and to preset new value: enter into "ALT" mode in motor stop state, then put new required value by using "UP","DN" and come out the operation mode by pressing both "SET" & "CLR", lastly clear and new value preset is done in the same time	6500
rota/ oFF/on	to decide a number of indicated factor in the order	*OFF:3 phase current(L1,L2,L3) , GF current,Load factor *ON:[3 phase current,Load factor] ,GF current] + [AWT] *interval time between each displayed factor : 3sec	oFF
rESEt/Hr/AuL-#	to decide how to reset trip state	*Hr:manual reset/Password input *Er:electrical reset : "Reset" key : "CLR" Key : Control power-off *AuL-#(n times):Auto reset by followed condition/max n=9 :n=1:possible to do only by entering password :n>1 ▶1(once) ~ (n-1) times: reset automatically according to preset reset time without entering password ▶n(last times) :possible to do only by entering password :trip state is kept on untill making password reset even though the control power is off(password lock) *Password reset:reset is done by comming out from operating mode after input password *Auto:only available for "OC" trip	Er
Aut/ setting value	to preset auto reset time	*time range :0(instant),1 ~ 300sec *If Hr is preset in "rESEt" mode, this mode becomes disable	--

t-Aut/ setting value	to preset total possible time available for executing defined times of auto reset	*possible total allowable time to have the preset number of auto reset *time range:30min~60min *only possible for over current trip *the preset time is counted from the instant of first trip and return to the preset condition for auto reset after the allowable time is elapsed *Password lock in Auto Reset :able in case the preset number of auto trip is done within preset total reset time :otherwise, the counted number of trip time is initialized to previous preset value *If Hr is preset in "rESet" mode,this mode becomes disable	--"
trIP /8 ~ 1/trip cause / trip value	to show latest number of 8 trip cause	*to show the number of 8 trip cause in the order *press "UP" or "DN" in the "trip" mode state, then trip cause and value is shown alternatively *press "CLR" or ""SET" to check next event or previous event *In order to enter setup state on the way of trip condition, press both "SET" and "CLR" in the same time, finally release	
Addr /Setting value	to put self-address to communic ate with PC	*to preset an address for 485 communication *rangeofnumber:#1 ~ #250	1
bPS /setting value	to decide communic ation speed	*to select communication speed :9.6/19.2/38.4/57.6/76.8/115.2kbps	9.6
Test	*to check if this relay is ready to work normally or not. *"tEst" is appeared in case the operator presses "CLR" key for 3 sec or more, then release pressed "CLR" key *main(95-96-98) & aux trip(05-06-08) output will be trip after counting down preset o-time(definite T-I) *make rest as pressing "CLR" key		


► Cab(calibration) Mode

This mode is appeared as pressing "SET" key for 5 sec or moe ,and is disappeared as "SET" key once more

Mode	Function/ range	Description	Factory Setting value
------	--------------------	-------------	--------------------------


P****	Password Input	*need to input password to adjust this mode group so that authorized person may be able to adjust. *How to input is same as it of main mode	0000
CrPEr	to have a calibration for phase "R" current	*Possible to adjust within +,- 50% by using "UP"."DN" key.	100
CSPeR	to have a calibration for phase "S" current		100
CtPEr	to have a calibration for phase "T" current		100
EcPEr	to have a calibration for GF current		100
PedIt	to change Password	*Possible to enter new digit by using "UP" or "DN" key after positioning a cursor on the required digit as using "SET" & "CLR" key with directional job *How to complete password change: firstly press "CLR" key to come out "setting mode" ,then press both "SET" & "CLR" key	

6. The order of Rotated Mode




7.Input-Output terminal

▸External ZCT Type




▸Embedded ZCT Type



DIV	Feature	Terminal	Description	
Input	Control power	A1(+),A2(-)	*85 ~ 260VAC,50/60Hz *90 ~ 370VDC	
Input	Z1,Z2	ZCT	*200mA/1.5mA in case using external ZCT : Basic Type *with Embeded ZCT :Optional Type	
Stae Indication	RED		Operating	Available for the converter of display meter type
	Green		Power/Stop	
	Yellow		Trip	
Output	Main Trip	*1c:95-96-98	*Over Current *Under Current *Locked Rotor *Phase Loss *Reverse Phase *Ground Fault *Current Unbalance *Shock/Stall	

Output	Aux trip	1c:05-06-08	*Au-o/oFF/Ec/AL/uc/Shoc/Ect *Selected factor is excluded from main trip
Output	485	TRX(+) TRX(-)	*RS485 digital communication

8. Operation of Control key











1."SET" key	*Press "SET" Key to enter into setting mode, then "P0000" (factory default password) is shown *Move cursor from first digit to right end digit by pressing "CLR" key,finally press once more, if password is not changed from factory default value, but if password is changed, then make required digit by using "UP"; "DN" key untill operator meets changed password. *If there is no input for 15sec or pressing both "SET" and "CLR"key, it can be entered into operating condition.
2.Changed feature of Setting Key	*After entering into posible state for preset , each key acts its job as follows :SET--->backward direction ,CLR---> foward direction,UP.DN--->able to select number or character in preset mode. *The previous mode based on setting mode is come out as pressing "SET" key during doing a prest job
3."SET" Key & "CLR" Key/to select MODE	*Possible to select Mode by using "SET" or "CLR" key
4."UP" key & "DN" Key/Adjust	*Possible to preset required value as selection a character or number by using UP/DOWN
5."SET" & "CLR" Key/Store	*The storage for preset data is completed by pressing both SET and CLR key in the same time or after 15sec is elapsed
6."CLR" key	*While each factor is rotated, one of rotated factor is fixed by pressing "CLR" key *After fixing a operating factor, the operator is able to rotate manually one by one as pressing "UP"(forwardly),"DN" (reversely)
To check preset value of each mode during operation	*possible to check value and mode as pressing “SET” key once during operation, *preset value and mode are appeared alternatively *possible to check next mode as pressing “CLR” Key *return to operating mode as pressing both “SET” and "CLR" key in the same time or waiting for 10sec without any touch

	*Not possible to change existed preset value
Test/Reset : "CLR" Key	*to check if this relay is ready to work normally or not. *"tEst" is appeared in case the operator presses test sw on the converter or "CLR" key for 3 sec or more, then release pressed test sw or "CLR" key *main(95-96-98) & aux trip(05-06-08) output will be trip after counting down preset o-time(definite T-I) *In case of display meter type, LED on the converter is Turned on after a trip *After making trip, press "CLR" key for the reset action
The centered LED of Control key	This is turned on in case 485(for CCL type) is executed normally
To check running current wave or trip instant current wave with 2 cycle term length	*Connect CCM/CCL with Note PC through 485↔232 USB converter,then execute "samdsp" monitoring program *Select CCM as pressing F2 Key of Note PC(default is CCM) *To check running current wave :put password in main window,then click "C" box *To check treip instant current wave: put password in main window,then click "200/100" box

9. Trip Indication


Trip cause and caused value is appeared alternatively

Trip	Display	Cause
Over current(oc)		*trip caused by over current in phase L1
Under current(Uc)		*trip caused by under current in phase L1
Current unbalance		*trip caused by unbalanced current in phase L1
GF		*trip caused by ground fault current
Phase loss		*trip caused by phase loss of phase L2 in load part


Reverse phase		*trip caused by reverse phase in load part
Shock/stall		*trip caused by instant shocking current in load part
Locked Rotor		*trip caused by locked rotor current in phase L2 during motor starts

11.T-I Characteristics

►Definite




►Inverse




12. Rotated indication

► 3 phase current(L1,L2,L3),Earth current,Load factor:"rota" mode/OFF




► phase current(L1,L2,L3)>GF current>Load factor>AWT> : "rota" mode/ON




13. Time Based Trip relay Output


- Over current protection/"Au-o" mode:OFF/"out" mode:b




- GF protection/"Au-o" mode:Ec(05-06-08)




- GF protection/"Au-o" mode:OFF(05-06-08)



14. Application Sequence Diagram



15. Dimension



16. Order form

DSP-1(Type)-2(Rating current)-3(Control Power)-4(ZCT Embedded)
-P(Optional)

Item	Reference Code	Description
DSP-CCL	DSP-CCL-10Z7	Panel Mounting Type. 0.5A ~ 10A. 85 ~ 260 VAC, 50/60Hz (90 ~ 370VDC), able to use external CT, able to use external ZCT, RS485
	DSP-CCL-70Z7	Panel Mounting Type. 5A ~ 70A. 85 ~ 260 VAC, 50/60Hz (90 ~ 370VDC), able to use external ZCT, RS485
	DSP-CCL-10Z7-ZCT	Panel Mounting Type. 0.5A ~ 10A. 85 ~ 260 VAC, 50/60Hz (90 ~ 370VDC), Embedded ZCT/not possible to use external CT, RS485
	DSP-CCL-70Z7-ZCT	Panel Mounting Type. 5A ~ 70A. 85 ~ 260 VAC, 50/60Hz (90 ~ 370VDC), Embedded ZCT/not possible to use external CT, RS485
Optional Order	DSP-VIPXXX-XXXXXXXXX-P	*Customised Software
Terminal Type	Basic reference code +T	Three terminal through CT hole of each phase is composed with one body

*Accessory

Item	Refeence	Description	Remarks
Cable	DSP -CABLE-12	1.2m	
	DSP -CABLE-18	1.8m	
	DSP -CABLE-30	3m	
	DSP -CABLE-50	5m	
ZCT	DSP -ZCT--XX	100mA/1.5mA	XX:Inner diameter of ZCT

17. Monitoring program "samsdp" Operation

17.1 General

- The user's PC basically based on Window XP and Window 7 should be embeded by following file
 - *.net framework 4.0(dotnetfx40_full_setup.exe) for MS Window :able to down load from MS or [www://samwhadsp.com](http://www.samwhadsp.com)
- PC has to use protocol converter(DSP-CMB/CMB-A) to connect between PC and DSP-CCM : CCM(TRX+,TRX-)/485 ↔ PC/USB, 232 Port

17.2 How to install "Samsdp"

- Down latest "samsdp-v(version number)" file provided by Samwha DSP Co.(Web page [www:samwhadsp.com](http://www.samwhadsp.com)) or CD, then make a release for compressed file.
- Check if "samsdp" folder is created in C:/ and make double click  SAMDSP, then followed window is shown




- If Comm Error is shown, make Pop-up window be shown as making click "COM" in the right bottom to preset communication condition



- Preset communication speed of DSP-CCM and select usable port to preset correct port in used port in Pop-up window.
Finally make SAVE and come out as making click "close symbol" in the upper right corner, then normal initial window is come and "Comm OK" sign is shown.



- F2 Key in PC works as toggle switch to select DSP-CCM or VIP-5CM
- Make click "Main" to monitor an operation state of DSP-CCM



- Make click "SET" after entering password to check a preset value of DSP-CCM or to preset changed preset value
 - LOAD : to show preset value of "samdsp" that is operating in PC
 - SAVE : to save changed preset value among loaded preset value in PC
 - SEND : to save loaded preset value in PC into converter of DSP-CCM
 - DN : to call preset value of converter of DSP-CCM

