




관통, 단자형 치수







LOAD 치수




Old-METER 치수







RS-485 통신모듈(레코드포함) 치수




METER CUTTING HOLL
(사각홀(64*43) 및 원형홀(65Φ))



NEW-METER 치수



"LOP"-rCS" Operation



* NOTE

- 1.The installing position for DSP is strongly required just like this diagram
- 2.b contact of aux output of MCCB should be connected with M1-M2 in order to confirm MCCB-open-state
- 3.Instant turn-over function("tover" mode) is not available for "RCS" operation